



Assembly of optional sleeves and purge adapters

Step 1:

To mount a sleeve, first unscrew the smoke column from the base. Now place the Steamulation Sleeve Upgrade Adapter with its flat side pointing downwards on top of the base.

Step 2:

Now take an optional Steamulation Purge Adapter and slide it from the bottom of the smoke column all the way up to the 18/8 grind, where there is an outer cone that holds the adapter. Now put an optional sleeve over the smoke column and insert it into the centre of the Steamulation Purge Adapter.

Step 3:

In the final step, please take the smoke column with the optional sleeve and purge adapter and put it through the Steamulation Sleeve Upgrade Adapter. Then screw the smoke column hand-tight to the base. It is advisable to first grasp the smoke column at the upper end and screw it into the thread a few turns. As soon as the smoke column engages in the thread, please pull the optional purge adapter upwards into the cone. The purge adapter and smoke column can then be easily tightened and loosened together.

Caution: Make sure that your optional sleeve is securely centred in both adapters so that no foreign air escapes.





Assembly of optional X-Blow Off and purge adapters

Step 1

To assemble the X-Blow Off in combination with a sleeve, first unscrew the smoke column from the base. Now screw the X-Blow Off smoke column extension onto your smoke column.

Step 2:

There are two X-Blow Off adapters. One upper and one lower. Now please take the X-Blow Off adapter suitable for the top. This adapter has a slightly tapered hole for the smoke column. Insert the smoke column from above through the hole.

At the upper end of the smoke column there is a suitable outer cone which holds the X-Blow Off adapter. Now put a sleeve over the smoke column from below. Then put the lower X-Blow Off adapter over the end of the smoke column and the sleeve.

Step 3:

In the last step, please take the smoke column incl. extension, X-Blow Adapter and sleeve and insert the smoke column thread into the thread on the top of the base. The lower X-Blow Off adapter slips over the corresponding external centring on the base.

Then screw the smoke column hand-tight to the base. It is advisable to first screw the smoke column slightly into the thread with the help of the inserted 18/8 smoke column adapter. Now take hold of the upper X-Blow Off adapter and pull it upwards, where it is held in place by the outer cone of the smoke column. Screw the smoke column on hand-tight. The X-Blow Off adapter and the smoke column can be easily tightened and loosened together without any tools needed.

Note:

- The X-Blow Off can only be mounted in conjunction with a sleeve.
- Each X-Blow Off adapter has four different positions. Blocking the blow off is also possible with each adapter. Do not block the upper and lower adapters at the same time, otherwise you will block the entire air outlet and the pressure will then have to escape via the smoke column, forcing water upwards.

