



## Assembly of optional sleeves and purge adapters

### Step 1:

To mount a sleeve, first unscrew the smoke column from the base. Now place the Steamulation Sleeve Upgrade Adapter with its flat side pointing downwards on top of the base.

### Step 2:

Now take an optional Steamulation Purge Adapter and slide it from the bottom of the smoke column all the way up to the 18/8 grind, where there is an outer cone that holds the adapter. Now put an optional sleeve over the smoke column and insert it into the centre of the Steamulation Purge Adapter.

### Step 3:

In the final step, please take the smoke column with the optional sleeve and purge adapter and put it through the Steamulation Sleeve Upgrade Adapter. Then screw the smoke column hand-tight to the base. It is advisable to first grasp the smoke column at the upper end and screw it into the thread a few turns. As soon as the smoke column engages in the thread, please pull the optional purge adapter upwards into the cone. The purge adapter and smoke column can then be easily tightened and loosened together.

Caution: Make sure that your optional sleeve is securely centred in both adapters so that no foreign air escapes.

