

INSTRUCTIONS FOR CLEANING YOUR SHISHA BEFORE FIRST USE

Hookahs made of V2A stainless steel or anodized aluminium

During the manufacture of high-quality stainless steel and anodized aluminum components, production-related residues from machining may occur, which can be removed completely by simple cleaning.

Hookahs made of V2A stainless steel with PVD coating

During transport and assembly, slight production-related residues may appear on the high-quality PVD-coated surfaces, but these can be easily removed by initial cleaning.

Instructions for initial cleaning

Therefore, please clean all parts of your hookah thoroughly with warm water and a little dish soap or a mild soap solution before using it for the first time. Rinse all parts carefully and clean them with a cloth. Only use soft cloths (e.g., microfiber) and make sure that there is no coarse dirt residue on the cloth or the surface of the parts to avoid rubbing the surface. Dry the surface with a soft cloth after cleaning to avoid water spots.

Do not use abrasive cleaning agents (scouring cream, scouring pads) or acidic substances, as these can permanently damage the surface. Cleaning should only be done by hand and never in the dishwasher.

After initial cleaning, regular cleaning on a daily basis ensures optimal hygiene, the best taste, and a long lifespan for your hookah.